

Choose the right ramp for the right application.

								16.5°	34"
								15.5°	32"
								16.1°	30"
							17.0°	15.0°	28"
							15.7°	13.9°	26"
							16.6°	14.5°	24"
							15.2°	13.2°	22"
							16.1°	13.8°	20"
							14.5°	12.4°	18"
							15.5°	12.8°	16"
							17.0°	13.5°	14"
							14.5°	11.5°	12"
							16.1°	12.0°	10"
							14.5°	10.8°	9"
							12.8°	9.6°	8"
							17.0°	11.2°	7"
							14.5°	9.6°	6"
							12.0°	8.0°	5"
							9.6°	6.4°	4"
							7.2°	4.8°	3"
2'	3'	4'	5'	6'	7'	8'	9'	10'	

Ramp Length (in feet)

Rise (in inches)

(Values rounded to the nearest 10th)

Use the Incline Chart to help determine the proper ramp length.

IMPORTANT: Consult your equipment's owner guide for proper degree of incline; never exceed its recommendations.

- Determine incline your chair or scooter is designed to climb.
- Measure the distance from the top step or landing to the ground (RISE).
- Refer to Incline Chart to find the proper ramp length.
- At any incline, use ramp only with a qualified helper.

* **NOTE:** 1 inch rise per 12 inch ramp length (ADA) = 4.8°

In this example, the SUITCASE® ramp shown is 5' in length. The two step rise is 12". When using the chart above this indicates an 11.5° rise.

